



SOLARIUM

IRRIGATION

TREADMILL

SAFETY WALL


WALKER

# Mounting aid brackets Adjustable Ground Bracket

Adjustable Ground Bracket / Article no. 630-4-20-00002



Variable fixing for bottom mounting. The automatic mounting aid is characterized by simple operation and assembly. The mounting aid can be fixed in the ground with the variable screw mounting for the floor mounting. Simply insert both supports into the base, slide on the climbing aid and screw it on - done! The boarding aid seamlessly connects to the arena wall.



### **PIONEERS IN EQUESTRIAN INNOVATION**






SOLARIUM



IRRIGATION





TREADMILL SAFETY WALL

WALKER







#### **Features**

Comes as a set of 2

## **PIONEERS IN EQUESTRIAN INNOVATION**











SOLARIUM

0

IRRIGATION 1

TREADMILL

SAFETY WALL

WALKER

#### **Specifications**

Length	40 cm
Width	40,5 cm
Drive system	90 cm
Basic material	Steel with powder coating
Weight	10 Kg
Heigth	90 cm

### **Contact details**

Q-Line Equestrian B.V. Haarbrinksweg 47 7678 RS Geesteren Tel. +31(0)546212361 info@Q-Line.com www.q-line.com

### **PIONEERS IN EQUESTRIAN INNOVATION**