


SOLARIUM

IRRIGATION

TREADMILL

SAFETY WALL

WALKER

Horse exerciser irrigation

No dust on the track

Track irrigation Basic / Article no. 23-3-10-00060



The hoof path irrigation keeps the walkway in the walker moist so that no dust is raised when the horses walk in the walker. Irrigation also ensures a more stable soil.

The high-quality bearing swivel under the walker is made to rotate constantly, unlike cheap "garden hose coupling solutions"


The sprinkler system is equipped with an automatic draining system which ensures that the water runs out of the pipe after every spraying so that it cannot freeze during periods of frost.

The spray tube is horse-proof and cannot become clogged.

- ✓ No dust
- ✓ Stable riding surface
- ✓ Reliable




Q-LINE



SOLARIUM




IRRIGATION



TREADMILL



SAFETY WALL



WALKER



Features

- The basic irrigation is suitable for the basic and the basic XL mill.
- The system will be located in the middle under the engine, so there must be a free passage in the middle
- For other brands, you may have to adjust something to get it right.

**SOLARIUM****IRRIGATION****TREADMILL****SAFETY WALL****WALKER**

Specifications

Suited for

Connection

Required liters

Required working pressure

Fixings

Included

Manual Valve

Suspension

Other

Nozzles

Q-Line walkers Basic / Basic XL

1/2" inner thread

150 l/h

2 bar

Included

Pipes on the arm

Drain valve

On push fence

Automatic drain

Spray tube 2 meters

Contact details

Q-Line Equestrian B.V.

Haarbrinksweg 47

7678 RS Geesteren

Tel. +31(0)546212361

info@Q-Line.com

www.q-line.com