



SOLARIUM



IRRIGATION



TREADMILL



SAFETY WALL



WALKER

Horse exerciser irrigation

No dust on the track

Track irrigation Basic / Article no. 23-3-10-00060




SOLARIUM

IRRIGATION

TREADMILL

SAFETY WALL

WALKER

The hoof path irrigation keeps the walkway in the walker moist so that no dust is raised when the horses walk in the walker. Irrigation also ensures a more stable soil.

The high-quality bearing swivel under the walker is made to rotate constantly, unlike cheap "garden hose coupling solutions"


The sprinkler system is equipped with an automatic draining system which ensures that the water runs out of the pipe after every spraying so that it cannot freeze during periods of frost.

The spray tube is horse-proof and cannot become clogged.

Image not found **No dust** unknown

Image not found **Stable riding surface**

Image not found **Reliable** unknown



Features

- The basic irrigation is suitable for the basic and the basic XL mill.
- The system will be located in the middle under the engine, so there must be a free passage in the middle
- For other brands, you may have to adjust something to get it right.

**SOLARIUM****IRRIGATION****TREADMILL****SAFETY WALL****WALKER**

Specifications

Suited for	Q-Line walkers Basic / Basic XL
Connection	1/2" inner thread
Required liters	150 l/h
Required working pressure	2 bar
Fixings	Included
Included	Pipes on the arm
Manual Valve	Drain valve
Suspension	On push fence
Other	Automatic drain
Nozzles	Spray tube 2 meters

Contact details

Q-Line Equestrian B.V.

Haarbrinksweg 47

7678 RS Geesteren

Tel. +31(0)546212361

info@Q-Line.com

www.q-line.com